

**Fit middle screen first ,  
wind top screen down and  
bottom screen up to meet .  
  
Reverse to access middle  
screen .**

AW31

3 X PZX Type 1 Vertical  
Adjustable Video Wall

